物聯網與微處理機系統設計 Internet of Things and Microprocessor System Design

Lecture 08 - CV on RPi

Lecturer: 陳彥安 Chen, Yan-Ann

YZU CSE

Modified from: NCTU IoT Course https://github.com/coldwufish/RaspPI



Outline

- Facial recognition
- Object detection



Outline

- Facial recognition
- Object detection



Preparation (1/2)

- Install OpenCV
- Load Linux V4L2 camera driver

\$ sudo modprobe bcm2835-v4l2



Preparation (2/2)

Download sample codes and unzip it.

\$ wget https://github.com/yachentw/yzucseiot/raw/main/lec08/face_detection.tar.gz

\$ tar -zxvf face_detection.tar.gz

```
pi@rpi4-A00:~/iot $ tar -zxvf face_detection.tar.gz
face_detection/
face_detection/image_face_detect.py
face_detection/haarcascade_eye_tree_eyeglasses.xml
face_detection/camera_face_detect.py
face_detection/haarcascade_frontalface_default.xml
```

\$ cd face_detection


```
pi@rpi4-A00:~/iot $ cd face_detection/
pi@rpi4-A00:~/iot/face_detection $
```

- Sample codes
 - Images from files: image_face_detect.py
 - Images from camera: camera_face_detect.py



Facial Detection

- Detect face of an image in the file system.
- \$ wget https://upload.wikimedia.org/wikipedia/zh/3/34/Lenna.jpg
- \$ mv Lenna.jpg ~/lena.jpg
- \$ python3 image_face_detect.py ../lena.jpg
- Specify the path to "lena.jpg" according to your environment.





image_face_detect.py

```
import sys
import cv2
# Get user supplied values
cascPath = "haarcascade frontalface default.xml"
imagePath = sys.argv[1]
if len(sys.argv) > 2:
    cascPath = sys.argv[2]
# Create the haar cascade
faceCascade = cv2.CascadeClassifier(cascPath)
if cv2. version .startswith('2'):
    PROP FRAME WIDTH = cv2.cv.CV CAP PROP FRAME WIDTH
    PROP FRAME HEIGHT = cv2.cv.CV CAP PROP FRAME HEIGHT
    HAAR FLAGS = cv2.cv.CV HAAR SCALE IMAGE
elif cv2.__version__.startswith('3') or cv2. version .startswith('4'):
    PROP FRAME WIDTH = cv2.CAP PROP FRAME WIDTH
    PROP FRAME HEIGHT = cv2.CAP PROP FRAME HEIGHT
    HAAR FLAGS = cv2.CV FEATURE PARAMS HAAR
# Read the image
image = cv2.imread(imagePath)
gray = cv2.cvtColor(image, cv2.COLOR BGR2GRAY)
```

```
# Detect faces in the image
faces = faceCascade.detectMultiScale(
    gray,
    scaleFactor=1.1,
    minNeighbors=5,
    minSize=(30, 30),
    flags=HAAR FLAGS
print ("Found {0} faces!".format(len(faces)))
# Draw a rectangle around the faces
for (x, y, w, h) in faces:
    cv2.rectangle(image, (x, y), (x+w, y+h), (0, 255, 0), 2)
cv2.imshow("preview", image)
cv2.waitKey(0)
cv2.destroyAllWindows()
```




Cascade Classification

- https://docs.opencv.org/2.4/modules/objdetect/doc/cascade_classification.html
- Haar feature-based cascade classifier for object detection
- The object detector described below has been initially proposed by Paul Viola [Viola01] and improved by Rainer Lienhart [Lienhart02].
- A classifier is trained with a few hundred sample views of a particular object (i.e., a face or a car), called positive examples.
 - Output 1: the region is likely to show the object (i.e., face/car)
 - Output 0: otherwise




Concept





Bitmap Images

• Example: black-and-white image





Bitmap Images


- Example: grayscale picture
 - 8 bits per pixel
 - This pixel depth allows 256 different intensities




154	108	198	216	52
61	168	148	52	45
72	80	55	134	39
89	129	232	204	155
156	99	118	125	83




Haar-Like Features






2. Line features




3. Center-surround features





Features (1/2)


- Pick a scale (ex: 24x24 pixels) for the feature
- Slide it across the image
- Compute the average pixel values under the white area and the black area.
- If the difference between the areas is above some threshold, the feature matches.





Features (2/2)

- 1. Calculate the average of white/black pixel
- 2. Calculate the difference



0	0	1	1
0	0	1	1
0	0	1	1
0	0	1	1

$$\Delta = black - whilte = 1$$

image

Edge feature


0	0	1	1
0	0	1	1
0	0	1	1
0	0	1	1

$$\Delta = \frac{0.6 + 0.8 + \dots}{8} - \frac{0.1 + 0.2 + \dots}{8}$$
$$= 0.7375 - 0.175 = 0.56$$



Integral Image (1/3)

- A quick and effective way of calculating the sum of values (pixel values) of a rectangular subset of a grid
- It can also used for calculating the average intensity within a given image.
- https://docs.opencv.org/2.4.13.7/modules/imgproc/doc/miscellaneous_transformations.html



Sum = Value(C) - Value(B) - Value(D) + Value(A)



Integral Image (2/3)

0.1	0.2	0.6	0.8
0.2	0.3	0.8	0.6
0.2	0.1	0.6	0.8
0.2	0.1	0.8	0.9



0.1	0.3	0.9	1.7
0.3	0.8	2.2	3.6
0.5	1.1	3.1	5.3
0.7	1.4	4.2	7.3


Original image


integral image



Integral Image (3/3)







0.1	0.3	0.9	1.7
0.3	0.8	2.2	3.6
0.5	1.1	3.1	5.3
0.7	1.4	4.2	7.3

0.1	0.3	0.9 _B	1.7
0.3	0.8	2.2	3.6
0.5	1.1	3.1	5.3
0.7	1.4	4.2	7.3

0.1 _A	0.3	0.9	1.7
0.3	0.8	2.2	3.6
0.5	1.1	3.1	5.3
0.7	1.4	4.2	7.3

1.7

3.6

5.3

7.3

0.1	0.3	0.9	1.7
0.3	0.8	2.2	3.6
0.5	1.1	3.1	5.3
0.7	1.4	4.2	7.3



AdaBoost


- Adaptive Boosting
 - Try out multiple weak classifiers over several rounds.
 - Select the best weak classifier in each round and combining the best weak classifiers to create a strong classifier.

Data point	Classifier 1	Classifier 2	Classifier 3	
P ₁	Pass	Fail	Fail	
P ₂	Pass	Pass	Pass	
P ₃	Fail	Pass	Pass	



Cascades

- Haar cascades consists of a series of weak classifiers
 - barely better than 50% correct
 - If an area passes a single classifier, go to the next classifier; otherwise, the area doesn't match.





Visualization

https://vimeo.com/12774628





Recall

```
while True:
   # Capture frame-by-frame
    ret, frame = cap.read()
    gray = cv2.cvtColor(frame, cv2.COLOR_BGR2GRAY)
   faces = faceCascade.detectMultiScale(
        gray,
        scaleFactor=1.1,
        minNeighbors=5,
        minSize=(30, 30),
       flags=HAAR_FLAGS
```



Related Parameters

- https://docs.opencv.org/2.4/modules/objdetect/doc/cascade_classification.html#cascadecl assifier-detectmultiscale
- detectMultiScale
 - cascade Haar classifier cascade (OpenCV 1.x API only). It can be loaded from XML or YAML file using Load(). When the cascade is not needed anymore, release it using cvReleaseHaarClassifierCascade(&cascade).
 - image Matrix of the type CV_8U containing an image where objects are detected.
 - objects Vector of rectangles where each rectangle contains the detected object.
 - scaleFactor Parameter specifying how much the image size is reduced at each image scale.
 - minNeighbors Parameter specifying how many neighbors each candidate rectangle should have to retain
 it.
 - flags Parameter with the same meaning for an old cascade as in the function cvHaarDetectObjects. It is not used for a new cascade.
 - minSize Minimum possible object size. Objects smaller than that are ignored.
 - maxSize Maximum possible object size. Objects larger than that are ignored.






Facial Detection

Get images from camera

\$ python3 camera_face_detect.py






Eyes Detection

- https://docs.opencv.org/3.4/db/d28/tutorial_cascade_classifier.html
- Eyes detection
 - Adjust detectMultiScale()

\$ python3 camera_face_detect.py haarcascade_eye_tree_eyeglasses.xml





More Classifiers

https://github.com/opencv/opencv/tree/master/data/haarcascades

§9 master → opencv / data / haarcascades /
This branch is up to date with 4.x.
alalek fix files permissions
haarcascade_eye.xml
haarcascade_eye_tree_eyeglasses.xml
haarcascade_frontalcatface.xml
haarcascade_frontalcatface_extended.xml
haarcascade_frontalface_alt.xml
haarcascade_frontalface_alt2.xml
haarcascade_frontalface_alt_tree.xml
haarcascade_frontalface_default.xml
haarcascade_fullbody.xml
haarcascade_lefteye_2splits.xml
haarcascade_licence_plate_rus_16stages.xml
haarcascade_lowerbody.xml
haarcascade_profileface.xml
haarcascade_righteye_2splits.xml
haarcascade_russian_plate_number.xml
haarcascade_smile.xml
haarcascade_upperbody.xml



Reference

- Online resource
 - Facial Detection
 - https://www.youtube.com/watch?v=sWTvK72-SPU
 - Computer Vision Haar-Features
 - https://www.youtube.com/watch?v=F5rysk51txQ
 - Computer Vision Integral Images
 - https://www.youtube.com/watch?v=x41KFOFGnUE
 - Recognition Part II: Face Detection via AdaBoost
 - https://courses.cs.washington.edu/courses/cse455/16wi/notes/15_FaceDetection.pdf



FAQ

- Q: Program error with "Address in use" or "Camera problem"?
- A: Check if you stop/suspend your program by "ctrl+z".

```
pi@rpi4-A00:~/iot/lec08/mjpg $ python3
Python 3.7.3 (default, Jul 25 2020, 13:03:44)
[GCC 8.3.0] on linux
Type "help", "copyright", "credits" or "license" for more information.
>>>
[2]+ Stopped python3
```



\$ jobs

```
pi@rpi4-A00:~/iot/lec08/mjpg $ jobs
[1]- Stopped python3 app-camera.py
[2]+ Stopped python3
```

Resume the program

```
$ fg <#>
```

```
pi@rpi4-A00:~/iot/lec08/mjpg $ fg 1
python3 app-camera.py
 * Debugger is active!
 * Debugger PIN: 308-914-434
```

pi@rpi4-A00:~/iot/lec08/mjpg \$ fg 2 python3

- Use "ctrl+c" to terminate the program.
- Use "exit()" to exit python shell.

```
pi@rpi4-A00:~/iot/lec08/mjpg $ fg 2
python3
>>> exit()
```



Find the program number

\$ ps -aux | grep python3

```
p1@rpi4-A00:~/iot/lec08/mjpg $ ps -aux | grep python3
         5007 0.5
                     0.1 14960 7456 pts/0
                                                \mathbf{T}
                                                     00:02
                                                             0:00 python3
         5009 16.8 1.6 301500 64460 pts/0
                                                     00:02
                                                             0:02 python3 app-cam
era.py
          5013 13.3 1.0 297456 40640 pts/0
                                                T1
                                                     00:02
                                                             0:01 /usr/bin/python
 app-camera.py
          5019 0.0 0.0
                           7348
                                  564 pts/0
                                                S+
                                                     00:02
                                                             0:00 grep --color=au
to python3
```

\$ sudo kill -9 <PID#>

```
pi@rpi4-A00:~/iot/lec08/mjpg $ sudo kill -9 5009
[2]+ Killed python3 app-camera.py
```

```
pi@rpi4-A00:~/iot/lec08/mjpg $ ps -aux | grep python3
pi 5007 0.0 0.1 14960 7456 pts/0 T 00:02 0:00 python3
pi 5040 0.0 0.0 7348 568 pts/0 S+ 00:04 0:00 grep --color=au
to python3
```




Outline

- Facial recognition
- Object detection



Object Detection



src: https://medium.com/zylapp/review-of-deep-learning-algorithms-for-object-detection-c1f3d437b852



Object Detection

- https://youtu.be/gGqVNuYol6o
- https://github.com/EdjeElectronics/TensorFlow-Object-Detection-on-the-Raspberry-Pi/blob/master/Pet_detector.py





Object Detection of TF

- https://github.com/tensorflow/models/tree/master/research/object_detection
- An open source framework built on top of TensorFlow that makes it easy to construct, train and deploy object detection models.






TensorFlow

- TensorFlow is an end-to-end open source platform for machine learning.
- It has a comprehensive, flexible ecosystem of tools, libraries, and community resources
 - Let researchers push the state-of-the-art in ML
 - Give developers the ability to easily build and deploy ML-powered applications.

Solutions to common ML problems

Simple step-by-step walkthroughs to solve common ML problems with TensorFlow.





Object Detectors

Speed/accuracy trade-offs for modern convolutional object detectors.




Figure 1: High level diagrams of the detection meta-architectures compared in this paper.

 "Speed/accuracy trade-offs for modern convolutional object detectors." Huang J, Rathod V, Sun C, Zhu M, Korattikara A, Fathi A, Fischer I, Wojna Z, Song Y, Guadarrama S, Murphy K, CVPR 2017



Required Packages

- Install dependency packages...
 - Tensorflow
 - Dependencies
 - Protocol Buffers
 - Object Detection API
- Installation reference
 - https://github.com/EdjeElectronics/TensorFlow-Object-Detection-on-the-Raspberry-Pi
 - https://github.com/PINTO0309/Tensorflow-bin/



Installations of TF

Log into your RPi and open a console to execute the following commands.

```
$ cd ~
```

\$ wget "https://raw.githubusercontent.com/PINTO0309/Tensorflow-bin/master/tensorflow-1.15.0-cp37-cp37m-linux_armv7l_download.sh"

\$ sh tensorflow-1.15.0-cp37-cp37m-linux_armv7l_download.sh

\$ sudo pip3 install tensorflow-1.15.0-cp37-cp37m-linux_armv7l.whl



Installation of Protoc

- Protocol buffer
 - A package that implements Google's Protocol Buffer data format.

\$ sudo apt-get install protobuf-compiler

Confirm if protocol buffer is installed.

\$ protoc



Protocol Buffers

- https://developers.google.com/protocol-buffers/
 - Protocol buffers are a language-neutral, platform-neutral extensible mechanism for serializing structured data.

```
message Person {
  required string name = 1;
  required int32 id = 2;
  optional string email = 3;
}
```

What are protocol buffers?

Protocol buffers are Google's language-neutral, platform-neutral, extensible mechanism for serializing structured data – think XML, but smaller, faster, and simpler. You define how you want your data to be structured once, then you can use special generated source code to easily write and read your structured data to and from a variety of data streams and using a variety of languages.

Learn more

```
Person john = Person.newBuilder()
    .setId(1234)
    .setName("John Doe")
    .setEmail("jdoe@example.com")
    .build();
output = new FileOutputStream(args[0]);
john.writeTo(output);
```

Pick your favorite language

Protocol buffers currently support generated code in Java, Python, Objective-C, and C++. With our new proto3 language version, you can also work with Dart, Go, Ruby, and C#, with more languages to come.

```
C++ C# Dart Go Java Pythor
```



How do I start?

- 1. Download and install the protocol buffer compiler.
- 2. Read the overview.
- 3. Try the tutorial for your chosen language.





TF Models

- Setup TensorFlow directory structure and environment variable.
- Download models and examples built with TensorFlow.

```
$ cd ~
```

\$ mkdir tensorflow1

\$ cd tensorflow1

\$ git clone --depth 1 https://github.com/tensorflow/models.git



Configurations

- Compile the Protocol Buffer files (.proto) used by the Object Detection API.
- The .proto files are located in /research/object_detection/protos.
- \$ cd /home/pi/tensorflow1/models/research
- \$ protoc object_detection/protos/*.proto --python_out=.
- Reboot the system
- \$ sudo reboot



Download Models

- Connect to your RPi with VNC Viewer and open a terminal.
- Change directory to the "object detection"

\$ cd /home/pi/tensorflow1/models/research/object_detection

- Download the SSD_Lite model from the TensorFlow detection model zoo.
 - The model zoo is Google's collection of pre-trained object detection models that have various levels of speed and accuracy.
 - SSD: Single Shot Multibox Detector
 - MobileNets: Efficient Convolutional Neural Networks for Mobile Vision Applications

\$ wget http://download.tensorflow.org/models/object_detection/ssdlite_mobilenet_v2_coco_2018_05_09.tar.gz

\$ tar -xzvf ssdlite_mobilenet_v2_coco_2018_05_09.tar.gz



Object Detection

Download a sample program "Object_detection_picamera.py".

\$ https://raw.githubusercontent.com/yachentw/yzucseiot/main/lec08/Object_detection_picamera.py


Run the sample program

\$ python3 Object_detection_picamera.py

- You have to wait for a while, then a new window will pop up.
- Press 'q' to quit.



Object Detection





COCO-trained Models

https://github.com/tensorflow/models/blob/master/research/object_detection/g3doc/tf1_detection_zoo.md

COCO-trained models

Model name	Speed (ms)	COCO mAP[^1]	Outputs
ssd_mobilenet_v1_coco	30	21	Boxes
ssd_mobilenet_v1_0.75_depth_coco ☆	26	18	Boxes
ssd_mobilenet_v1_quantized_coco ☆	29	18	Boxes
ssd_mobilenet_v1_0.75_depth_quantized_coco ☆	29	16	Boxes
ssd_mobilenet_v1_ppn_coco ☆	26	20	Boxes
ssd_mobilenet_v1_fpn_coco ☆	56	32	Boxes
ssd_resnet_50_fpn_coco ☆	76	35	Boxes
ssd_mobilenet_v2_coco	31	22	Boxes
ssd_mobilenet_v2_quantized_coco	29	22	Boxes
ssdlite_mobilenet_v2_coco	27	22	Boxes
ssd_inception_v2_coco	42	24	Boxes
faster_rcnn_inception_v2_coco	58	28	Boxes
faster_rcnn_resnet50_coco	89	30	Boxes
faster_rcnn_resnet50_lowproposals_coco	64		Boxes

92	30	Boxes
106	32	Boxes
82		Boxes
620	37	Boxes
241		Boxes
1833	43	Boxes
540		Boxes
771	36	Masks
79	25	Masks
470	33	Masks
343	29	Masks
	106 82 620 241 1833 540 771 79	106 32 82 620 37 241 1833 43 540 771 36 79 25 470 33





COCO (Common Objects in Context)

- COCO is a large-scale object detection, segmentation, and captioning dataset. COCO has several features:
 - Object segmentation
 - Recognition in context
 - Superpixel stuff segmentation
 - 330K images (>200K labeled)
 - 1.5 million object instances
- http://cocodataset.org

- 80 object categories
- 91 stuff categories
- 5 captions per image
- 250,000 people with keypoints








MobileNet

- Utilize depthwise separable convolutional neural network to reduce the computation.
 - Smaller model size: Fewer number of parameters
 - Smaller complexity: Fewer Multiplications and Additions (Multi-Adds)
- Suitable for portable devices.

(a) Conventional Convolutional Neural Network

Table 4. Depthwise Separable vs Full Convolution MobileNet

Model	ImageNet	Million	Million
	Accuracy	Mult-Adds	Parameters
Conv MobileNet	71.7%	4866	29.3
MobileNet	70.6%	569	4.2



(b) Depthwise Separable Convolutional Neural Network






SSD

SSD

YOLO





Tracing Code

• In Object_detection_picamera.py:

```
ret, frame = camera.read()
            frame rgb = cv2.cvtColor(frame, cv2.COLOR BGR2RGB)
192
193
           frame_expanded = np.expand_dims(frame_rgb, axis=0)
194
195
           · #-Perform the actual detection by running the model with the image as input
196
     (boxes, scores, classes, num) = sess.run(
     [detection boxes, detection scores, detection classes, num detections],
197
     feed dict={image tensor: frame expanded})
198
199
           # Draw the results of the detection (aka 'visulaize the results')
           vis util.visualize boxes and labels on image array(
     frame,
     np.squeeze(boxes),
     np.squeeze(classes).astype(np.int32),
     np.squeeze(scores),
     category index,
    use normalized coordinates=True,
               line thickness=8,
               min score thresh=0.4)
            # print(boxes[0][:10])
210
211
            # print(np.squeeze(classes))
            # print(np.squeeze(scores))
212
           # print(category index)
213
```



Tracing Code

print(np.squeeze(classes))

print(np.squeeze(scores))

```
0.96914864 0.
                                     Θ.
                                                             Θ.
                                     Θ.
                                                 Θ.
                                                             Θ.
                                     Θ.
                        Θ.
                                                             Θ.
                                     Θ.
                        Θ.
                                     Θ.
                                                 Θ.
                                                             Θ.
                        Θ.
                                     Θ.
                                                             Θ.
                                     Θ.
                                                             Θ.
                        Θ.
                                     Θ.
                                                 Θ.
                                                             Θ.
                        Θ.
                                     Θ.
                                                             Θ.
                                     Θ.
                                                             Θ.
                        Θ.
                                    Θ.
                                                 Θ.
                                                             Θ.
                        Θ.
                                     Θ.
                                                             Θ.
                                     Θ.
                                                             Θ.
                        Θ.
                                     Θ.
                                                             Θ.
                                                 Θ.
                        Θ.
                                     Θ.
                                                             Θ.
```



print(category_index)

'name': 'motorcycle'}, 5: {'id': 5, 'name': 'bus'}, 7: {'id': 7, 'name': 'train'}, 8: {'id': 8, {'id': 9, 'name': 'boat'}, 10: {'id': 10, 'name': 'traffic li 'fire hydrant'}, 13: {'id': 13, 'name': 'stop sign 'parking meter'}, 15: {'id': 15, 'name': 'bench'}, 'bird'}, 17: {'id': 17, 'name': 'cat'}, 18: {'id': 18, 'horse'}, 20: {'id': 20, 'name': 'sheep'}, 21 'cow'}, 22: {'id': 22, 'name': 'elephant'}, 23: {'id': 'bear'}, 24: {'id': 24, 'name': 'zebra'}, 25: {'id': 25, 'name': 'giraff {'id': 27, 'name': 'backpack'}, 28: {'id': 28, 'name': 'umbrella'}, 31: 'handbag'}, 32: {'id': 32, 'name': 'tie'}, 33: {'id': 33, 'suitcase'}, 34: {'id': 34, 'name': 'frisbee'}, 35: {'id': 35, 'name': {'id': 36, 'name': 'snowboard'}, 37: {'id': 37, 'name': 'sports ball id': 40, 'name': 'baseball glove'}, 41: {'id': 41, 'name': 'skateboard'}, 42: 'surfboard'}, 43: {'id': 43, 'name': 'tennis racket'}, 44: {'id 'bottle'}, 46: {'id': 46, 'name': 'wine glass'}, 47: {'id': 47, 'cup'}, 48: {'id': 48, 'name': 'fork'}, 49: {'id': 49, 'name': 'knife'}, 'name': 'spoon'}, 51: {'id': 51, 'name': 'bowl'}, 52: {'id': 52, 'banana'}, 53: {'id': 53, 'name': 'apple'}, 54: {'id': 54, 'name': wich'}, 55: {'id': 55, 'name': 'orange'}, 56: {'id': 56, 'name': 'broccoli'}, 57 'name': 'carrot'}, 58: {'id': 58, 'name': 'hot dog'}, 59: {'id': 59 60: {'id': 60, 'name': 'donut'}, 61: {'id': 61, 'name': e'}, 62: {'id': 62, 'name': 'chair'}, 63: {'id': 63, 'name': 'couch'}, 64: {'id 64, 'name': 'potted plant'}, 65: {'id': 65, 'name': 'bed'}, 67: {'id': 67, 'dining table'}, 70: {'id': 70, 'name': 'toilet'}, 72: {'id': 72, tv'}, 73: {'id': 73, 'name': 'laptop'}, 74: {'id': 74, 'name': 'mouse'}, 'name': 'remote'}, 76: {'id': 76, 'name': 'keyboard'}, 77: {'id': 77, 'oven'}, 80: {'id': 80, 'name': 'toaster'}, 81: {'id': 81, 'name': 'sink'}, 82 {'id': 82, 'name': 'refrigerator'}, 84: {'id': 84, 'name': 'book'}, 85: {'id': 'name': 'clock'}, 86: {'id': 86, 'name': 'vase'}, 87: {'id': 87, 'name': issors'}, 88: {'id': 88, 'name': 'teddy bear'}, 89: {'id': 89, 'name': 'hair dri 90: {'id': 90, 'name': 'toothbrush'}}



Observations

- Try to detect an object (ex: mouse)
 - Observe the name and probability on bounding box.
 - Check the corresponding value from program messages.
 - Extend the code to print some logs
 - Ex: boxes, scores, classes.
- Explain your observation to the TA.
 - What is the meanings of these 4 values in boxes?

```
[0.05501831 0.06906126 0.44656342 0.5512208 ]

[0.04684409 0.0718818 0.44538224 0.5478414 ]

[0.16795996 0.09565087 0.5515163 0.55543965]

[0.41594383 0.13077407 0.79498076 0.5818809 ]


[0.5129771 0.16718942 0.8876519 0.6002387 ]


[0.50959575 0.1832101 0.8822446 0.61404395]
```



Lab

- Show a red rectangle while an object is in the 4th quadrant.
 - Plot a red rectangle from the center to the bottom right corner.
- "Detected" means that the bounding box of the object is fully included in the 4th quadrant.






Detected!

Not Detected!



TensorFlow Lite

- TensorFlow Lite is an open source deep learning framework for on-device inference.
- https://www.tensorflow.org/lite/examples/





USB Accelerator

A USB accessory that brings machine learning inferencing to existing systems.
 Works with Raspberry Pi and other Linux systems.



